




Team Decals Application Instructions




1. Minimum equipment required: Decal Softeners (Recommended Microscale Micro Set and Micro Sol), Tweezers, Craft knife, Brush size 1. All equipment is available at www.mysubbuteo.com




2. Your figures will need some preparation before starting with the decals. Remove all the mold lines with the knife or some emery paper. You can even fit them on the bases and apply a coat of satin acrylic varnish to improve the grip of the decals.



3. Use the craft knife to slice each kit across the cut lines. Use the spare kits first as you may have to try a couple of times and do some trimming before find the right fit for the figure type you are using.



4. Use the Decal Softener (Micro Sol on the decal, Micro Set on the figure or a combination of your choice) to soften one decal piece at a time. Let it soak for a few seconds.



5. Carefully lift the decal with the tweezers and place it on the figure. Use the brush dipped in Micro Set/Sol to soften the decal more or to move it slightly to the right place. When finished let the figures to dry for 24hrs. Apply a thin coat of satin spray varnish.



6. Paint the skin parts and all areas the decals did not reach with a fine brush and enamel or acrylic colours. The colour codes (Humbrol) for each team can be downloaded from www.mysubbuteo.com/site/Team_Designs.html.



7. You can decorate your bases with vinyl self-adhesive disk covers (sold separately). Instructions can be found at www.mysubbuteo.com/site/Disk_Inserts.html

Decals Designed & Printed by
www.mysubbuteo.com

Made in the UK, York, North Yorkshire
Copyright 2009 MySubbuteo